

## Physical installation instructions

IKI Electric heaters 6 and 6,6 kW with UKU Glass Black control unit

Models: Pillar IKI 6,6 kW, Wall IKI 6 kW and Corner IKI 6 kW

The temperature sensor should be installed no less than 39.4 inches (1000 mm) from an undirected air vent income, or less than 19.7 inches (500 mm) from a directed air vent.

