

PHYSICAL INSTALLATION INSTRUCTIONS

IKI Electric Heaters 6 and 6.6 kW with UKU control unit (glass black)
US Models: IKI Pillar 6.6 kW, IKI Wall 6 kW and IKI Corner 6 kW

The temperature sensor should be installed no less than 39.4 inches (1000 mm) from an undirected air vent income, or less than 19.7 inches (500 mm) from a directed air vent.



You can download the IKI app by searching "IKI" in the app store

