

## PHYSICAL INSTALLATION INSTRUCTIONS

IKI Electric Heaters 9 kW with UKU control unit (glass black)  
US Models: IKI Pillar 9 kW, IKI Wall 9 kW and IKI Corner 9 kW

The temperature sensor should be installed no less than 39.4 inches (1000 mm) from an undirected air vent income, or less than 19.7 inches (500 mm) from a directed air vent.



You can download the IKI app by searching "IKI" in the app store

